



Doc. No.	NDP 231M-05
----------	-------------

MAINTENANCE MANUAL

YAMADA AIR-OPERATED DOUBLE DIAPHRAGM PUMP

NDP-20-PP series

NDP-25-PP series

NDP-25-PN series

WARNING



- For your own safety, be sure to read these procedures carefully before performing maintenance on this product. After reading this document, be sure to keep it handy for future reference.

This maintenance manual covers what you should know about maintenance of the Yamada NDP-20-PP series and NDP-25-PP and NDP-25-PN series Diaphragm Pumps.

This edition is based on the standards for the March 2018 production run. Remember, the specifications are always subject to change; therefore, some of the information in this edition may not apply to new specifications.

- **Warnings and Cautions**

For safe use of this product, be sure to note the following: In this document, warnings and cautions are indicated by symbols. These symbols are for those who will operate this product and for those who will be nearby, for safe operation and for prevention of personal injury and property damage. The following warning and caution symbols have the meanings described below. Be sure to remember their meanings.



WARNING : If you ignore the warning described and operate the product in an improper manner, there is danger of serious bodily injury or death.



CAUTION : If you ignore the caution described and operate the product in an improper manner, there is danger of personal injury or property damage.

Furthermore, to indicate the type of danger and damage, the following symbols are also used along with those mentioned above:



This symbol indicates a DON'T, and will be accompanied by an explanation on something you must not do.



This symbol indicates a DO, and will be accompanied by instructions on something you must do in a certain situation.

WARNING



- Before starting maintenance work, cut off the feed air and clean the pump. If air pressure or residue remain in the pump, there is danger of explosion, or possible poisoning resulting in serious injury or death if chemicals adhere to the skin or are accidentally swallowed. (For details on cleaning the pump, refer to Chapter 6 of the Operation Manual.)



- When replacing parts, be sure to use the recommended genuine parts or Equivalents. Use of other parts may cause a malfunction of the product. (Refer to Exploded View and Reminder to order correct item on the separate sheets.)

CAUTION



- When it is instructed that special tools must be used, be sure to use the specified tools. Otherwise, the pump may be damaged.



- Refer to 10.1 "Specifications" in the Operation Manual. Also, remember that the pump is heavy, and extreme care must be taken when lifting it.

Table of Contents

-Warnings and Cautions

-Table of Contents


1. Principles of operation	1
2. Tools, etc	
2.1 General tools	1
2.2 Special tools	1
2.3 Misc.	1
3. Ordering Replacement parts	1
4. Balls and Valve seats	
4.1 Removal	2
4.2 Inspection	4
4.3 Installation	4
5. Diaphragm and Center rod	
5.1 Removal	5
5.2 Inspection	6
5.3 Installation	7
6. Throat bearing and Pilot valve Assembly	
6.1 Removal	8
6.2 Inspection	8
6.3 Installation	9
7. C Spool Valve Assembly and Sleeve Assembly	
7.1 Removal	9
7.2 Inspection	10
7.3 Installation	10
8. Retightening of Tie rods	11

1. Principles of operation

There are two diaphragms fixed to the center rod, one at each end. When compressed air is supplied to air chamber b (right side, see Fig. 1.1), the center rod moves to the right, the material in material chamber B is pushed out, and at the same time material is sucked into material chamber A.

When the center rod is moved full-stroke to the right, the air switch valve is switched, compressed air is sent to air chamber a (left side, see Fig.1.2), and the center rod moves to the left. The material in material chamber A is pushed out, and at the same time material is sucked into material chamber B.

Through repetition of this operation, material is repeatedly taken in and discharged out.





2. Tools, etc.

2.1 General tools

- Socket wrenches 10mm, 12mm, 13mm, 17mm, 22mm
- Hexagonal box wrenches 5mm
- Open-end wrenches 12mm, 13mm, 22mm
- Adjustable angle wrenches
- Phillips head screw driver

2.2 Special tools

- Accessory tool (included) Purpose: Removing the center disk BP_, BV_)
 - Sleeve remover (sold separately) Purpose: For removing sleeves



2.3 Misc.

- Assembly oil Turbine oil none addition class 1 (equivalent ISO VG32 grade)
- Nuts M14×1.5
- Grease Urea grease grade (NLGI) No. 2


3. Ordering Replacement parts

For accurate and speedy shipment of parts, be sure to order the right parts for your model to distributor. Indicate the part numbers, descriptions, and quantities.


4. Balls and Valve seats

4.1 Removal


-BA_, BS_




- Remove the 4 retainer bolts from the out manifold, and remove the out manifold. [Fig.4.1]



- Remove the O ring, valve stopper, ball and valve seat. [Fig.4.2]




- Remove the 4 retainer bolts from the in manifold, and remove the in manifold and pump bases. [Fig.4.3]



- Remove the O ring, valve seat, ball and valve stopper. [Fig.4.4]


-BP_, BV_




- Remove the 4 retainer nuts from the upper side of tie rods, and remove the out manifold. [Fig.4.5]

<NOTE>


- When the retainer nuts on both sides of the tie rod are removed, the IN MANIFOLD can be removed.



- Remove the O ring, valve stopper, ball and valve seat. [Fig.4.6]




- Pull out the tie rod, and remove the base and OUT MANIFOLD. [Fig.4.7]



- Remove the O ring, valve seat, ball and valve stopper. [Fig.4.8]

4.2 Inspection



- Ball [Fig.4.9]

Measure the outside diameter, and if it is outside the usable range, replace the ball.

Usable range of Ball


NDP-20-PP	Sø0.957 ~ Sø1.095 in {Sø24.3 ~ Sø27.8 mm}
NDP-25-PP NDP-25-PN	Sø1.240 ~ Sø1.421 in {Sø31.5 ~ Sø36.1 mm}

- Valve seat [Fig.4.10]

Measure the dimension shown at left, and if it is outside the usable range, replace the valve seat.

Usable range of Valve seat

	BA_, BS_	BP_, BV_
NDP-20-PP	0.134 ~ 0.335 in {3.4 ~ 8.5 mm}	0.130 ~ 0.319 in {3.3 ~ 8.1 mm}
NDP-25-PP NDP-25-PN	0.150 ~ 0.374 in {3.8 ~ 9.5 mm}	0.134 ~ 0.374 in {3.4 ~ 9.5 mm}



- O ring (other than PTFE)

If O ring is worn out or cracked, replace it.

4.3 Installation

For installation, see [Exploded View] on the separate sheet and install in the reverse order of disassembly.

Tightening torque for manifold retainer bolts

		C, N, E, V,	T, H, S,
NDP-20-PP	BA_	8 ft-lbf {10 N-m}	15 ft-lbf {20 N-m}
	BS_		
NDP-25-PP	BA_	8 ft-lbf {10 N-m}	25 ft-lbf {35 N-m}
	BS_		

Tightening torque for manifold retainer nuts

		C, N, E, V,	T, H, S,
NDP-20-PP	BP_	8 ft-lbf {10 N-m}	9 ft-lbf {12 N-m}
NDP-25-PP	BP_		
NDP-25-PN	BV_		


<NOTE>

- Make sure there is no dust on the seal surface and the seal is not damaged.
- Replace the PTFE O ring regardless of its condition.


5. Diaphragm and Center rod

5.1 Removal


-BA_, BS_ types



- Remove the ball and valve seat etc. (see [4.1 Removal BA_, BS_ types])
- Remove the 12 retainer bolts from the out chamber, and remove the out chamber. [Fig.5.1]



- Remove the nuts on both sides of the center rod. [Fig.5.2]
- After the nuts on one side have been removed, remove the center disk and diaphragm. Remove the diaphragm, center disk and center rod from the opposite side of the main body.



- Remove the nuts on the opposite side using the double nut. [Fig.5.3]
- Remove the coned disk spring, center disk and diaphragm.

-BP_, BV_ types




Fig.5.4

- Remove the ball and valve seat etc. (see [4.1 Removal])
- Remove the 12 retainer bolts from the out chamber, and remove the out chamber. [Fig.5.4]




Fig.5.5

- Remove the center disk from one side using the Accessory tool (special tool: Part No. 771244). [Fig.5.5]
- After the center disk (outside) has been removed, remove the diaphragm and the center disk (inside).
- Remove the center disk and center rod from the opposite side of the main body.




Fig.5.6

- Fix a double nut to one end of the center rod and take the diaphragm and center disk off the opposite end. [Fig.5.6]
- Be careful not to scratch or score the center rod.

5.2 Inspection




Fig.5.7

- Diaphragm
If the diaphragm is worn out or damaged, replace it.
Never replace just one-side diaphragm.

Guideline of diaphragm life

CR, NBR, EPDM	10,000,000 cycle
FKM	2,500,000 cycle
PTFE	3,000,000 cycle
TPEE, TPO	15,000,000 cycle

- Center rod [Fig.5.7]
Measure the diameter, and if it is outside the usable range, replace the center rod.


Usable range of center rod

$\phi 0.704 \sim \phi 0.709$ in { $\phi 17.9 \sim \phi 18.0$ mm}

5.3 Installation

-B_C, B_N, B_E, B_V, B_H, B_S types


For installation, see [Exploded View] on the separate sheet and install in the reverse order of disassembly.



- Apply grease to the center rod, and insert it into the main body.
- For B_H and B_S, attach O ring * into the grooves on both sides of the body. [Fig.5.8] [Fig.5.9]
- Keep the marking "OUTSIDE" to liquid end for CR, NBR, EPDM, FKM diaphragms. Keep the convex side to the outside for TPEE, TPO diaphragms.
- For BP_, BV_, tighten the center disk using the Accessory tool (special tool: Part No.771244).

Tightening torque for center rod

29 lbf-ft { 40 N-m }



- Draw the center disk to one side, (cf. Fig.5.8) and install the out chamber. Tighten the bolts temporarily.
- Draw the center disk to the opposite side, then turn the diaphragm over (cf. Fig.5.8). And install the out chamber. Tighten the bolts temporarily.
- After installation of the out chambers on both sides, place the pump on a flat surface and stand the pump upright for further assembly.

Tightening torque for out chamber.


NDP-20-PP	B_C,B_N,B_E,B_V	8 lbf-ft { 10 N-m }
	B_H,B_S	10 lbf-ft { 13 N-m }
NDP-25-PP NDP-25-PN	B_C,B_N,B_E,B_V	8 lbf-ft { 10 N-m }
	B_H,B_S	15 lbf-ft { 20 N-m }

<NOTE>

- Make sure there is no dust on the seal surface in order to prevent seal damaged.
- Tighten the bolts so that balance should be equal from both side on diagonal line with even torque.

-B_T type

For installation, see [Exploded View] on the separate sheet and install in the reverse order of disassembly.



- Apply grease to the center rod, and insert it into the main body.
- Attach O ring into the grooves on both sides of the body. [Fig.5.10] [Fig.5.11]
- Keep the convex side to the outside.
- Put the O rings to both sides of the diaphragm.
- For BPT, BVT, tighten the center disk using the Accessory tool (special tool: Part No. 771244)

Tightening torque for center rod

29 lbf-ft { 40 N-m }

- Tighten the out chamber temporarily at first.
- After installation of the out chambers on both sides, place the pump on a flat surface and stand the pump upright for further assembly.

Tightening torque for out chamber

NDP-20-PP	10 lbf-ft { 13 N-m }
NDP-25-PP NDP-25-PN	15 lbf-ft { 20 N-m }

<NOTE>

- Make sure there is no dust on the seal surface in order to prevent seal damage.
- Replace the PTFE O ring by O ring with new one.
- Tighten the bolts so that balance should be equal from both side on diagonal line with even torque.

6. Throat bearing and Pilot valve Assembly

6.1 Removal




Fig.6.1

- Remove the diaphragm and center rod (see [5.1 Removal]).
- Remove the 10 retainer screws from the body. [Fig.6.1]




Fig.6.2

- Draw out the valve seats and the pilot valve assembly. (both side) [Fig.6.2]
- Draw out the throat bearings. [Fig.6.2]




Fig.6.3

- Remove the packing from the throat bearing. [Fig.6.3]

6.2 Inspection




Fig.6.4


- Throat bearing [Fig.6.4]
Measure the inside diameter, and if it is outside the usable range, replace the throat bearing.

Usable range of throat bearing $\varnothing 0.710 \sim \varnothing 0.714$ in $\{\varnothing 18.03 \sim \varnothing 18.14 \text{ mm}\}$

- O ring, Packing
If the O ring is worn out or cracked, replace it.
- Pilot valve assembly
If the pilot valve is worn out or cracked, replace it.

6.3 Installation

For installation, see [Exploded View] on the separate sheet and install in the reverse order of disassembly.



Tightening torque for retainer screws


1.4 lbf-ft { 2 N-m }

<NOTE>


- Make sure there is no dust on the seal surface and the seal is not damaged.
- Apply grease to packing.
- Use a Phillips head screw driver to tighten screws that secure throat bearing
- Do not tighten the tapping screws too much.
(Be careful when power tool is used.)

7. C Spool Valve Assembly and Sleeve Assembly


7.1 Removal



- Remove the 4 retainer bolts from the valve body, and remove the valve body and gasket. [Fig.7.1]



- Remove the cap A with adjustable angle wrenches, remove packing and Draw out the C spool valve assembly. [Fig.7.2]



- Remove the sleeve using the sleeve remover (special tool: Part number 713148). [Fig.7.3]

7.2 Inspection




Fig.7.4

- C Spool Valve Assembly

Seal ring [Fig.7.4]

Measure the inside thick diameter, and if it is outside the usable range, replace the c spool valve assembly.

If the seal ring is worn out or cracked, replace c spool valve assembly.

Usable range of seal ring

0.1157 ~ 0.1189 in {2.94 ~ 3.02 mm}

- Sleeve Assembly [Fig.7.5]

Measure the inside diameter, and if it is outside the usable range, replace the sleeve assembly.

Usable range of sleeve

$\varnothing 0.733 \sim \varnothing 0.734$ in { $\varnothing 18.63 \sim \varnothing 18.65$ mm}




Fig.7.5

- O ring

If the O ring is worn out or cracked, replace it.

<NOTE>

- C Spool Valve Assembly and Sleeve Assembly must be replaced as a complete set. Unable to replace individual component.

7.3 Installation

For installation, see [Exploded View] on the separate sheet and install in the reverse order of disassembly.

Tightening torque for valve body installation bolts


5.5 lbf-ft { 7.5N-m }

<NOTE>

- Make sure there is no dust on the seal surface and it is not damaged.

- Install the sleeve at the center of the valve body. At this point, apply lubricating oil around the sleeve and O ring.

8. Retightening of Tie rods



- The torque should be applied on the occasion of
- (1) Right before the pump is installed.
- (2) There are any leaks of material on daily inspecting a pump.

- Metal type

		Retain bolts for the out chamber	Retain bolts for the manifold
NDP-20-PP	BAC, BAN, BAE, BAV BSC, BSN, BSE, BSV	8 lbf·ft { 10 N·m }	8 lbf·ft { 10 N·m }
	BAT, BST	10 lbf·ft { 13 N·m }	15 lbf·ft { 20 N·m }
	BAH, BAS BSH, BSS	10 lbf·ft { 13 N·m }	8 lbf·ft { 10 N·m }

		Retain bolts for the out chamber	Retain bolts for the manifold
NDP-25-PP	BAC, BAN, BAE, BAV BSC, BSN, BSE, BSV	8 lbf·ft { 10 N·m }	8 lbf·ft { 10 N·m }
	BAT, BST	15 lbf·ft { 20 N·m }	25 lbf·ft { 35 N·m }
	BAH, BAS BSH, BSS		

- Plastic type

		Retain bolts for the out chamber	Retain bolts for the manifold
NDP-20-PP	BPC, BPN, BPE, BPV	8 lbf·ft { 10 N·m }	8 lbf·ft { 10 N·m }
	BPT	10 lbf·ft { 13 N·m }	9 lbf·ft { 12 N·m }
	BPH, BPS	10 lbf·ft { 13 N·m }	8 lbf·ft { 10 N·m }

		Retain bolts for the out chamber	Retain bolts for the manifold
NDP-25-PP NDP-25-PN	BPC, BPN, BPE, BPV BVE, BVV	8 lbf·ft { 10 N·m }	8 lbf·ft { 10 N·m }
	BPT, BVT, BVH, BVS	15 lbf·ft { 20 N·m }	9 lbf·ft { 12 N·m }
	BPH, BPS	15 lbf·ft { 20 N·m }	8 lbf·ft { 10 N·m }

<NOTE>

- Tighten the bolts so that balance should be equal from both side on diagonal line with even torque.
- Retighten the Out chamber and then the manifold in this order. [Fig.8.1]

YAMADA AMERICA, INC

955 E. ALGONQUIN RD., ARLINGTON HEIGHTS, IL 60005, USA
PHONE: 1-847-631-9200 or 1-800-990-7867 (Toll Free) FAX : 1-847-631-9273
www.yamadapump.com

Manufactured by:

YAMADA CORPORATION

International Department
1-1-3 CHOME, MINAMI MAGOME, OHTA-KU, TOKYO, 143-8504, JAPAN
PHONE : +81-(0)3-3777-0241 FAX : +81-(0)3-3777-0584